

Ordering code

This page explains how to build the **ordering code** of the NL-EB15 safety device. The code selects the model, the beam count, the beam space, the output type, and the sensing distance.

NL-EB15	- 10	20	P	C	C	- 2
Model	Beams	Beam space	Output signal	Output contact	Scanning method	Sensing distance
NL-EB15 series	04,06,08,10,12	10,20,40mm	P=PNP, N=NPN	C=normally close	C=cross scanning, P=parallel scanning	0,5⇒0.1 to 0,5m 2⇒0.1 to 2m 4⇒01, to 4m

Example: NL-EB15-10-20-P-C-C-2

How to build the code

- **Model:** NL-EB15 series. - **Beams:** number of beams (04, 06, 08, 10, 12). - **Beam space:** 10, 20, or 40 mm. - **Output signal:** P = PNP, N = NPN. - **Output contact:** C = normally close. - **Scanning method:** C = cross scanning, P = parallel scanning. - **Sensing distance:** 0.5, 2, or 4 m.

From:

<https://www.nilab.at/dokuwiki/> - **NiLAB GmbH Knowledgebase**

Permanent link:

https://www.nilab.at/dokuwiki/doku.php?id=en:nl_eb15_safety:ordering

Last update: **2026/09/11 07:59**

