
Fixing accessories

This page shows the **fixing accessories** of the Motolab actuator. The accessories are used to mount the actuator and to connect the output.



Notes

- The fixing accessories are matched to the actuator size. - Use the correct mounting accessories for the application. - The output screw is M16x1.5 mm; refer to the mechanical construction page. - For the ordering and the selection, refer to the ordering code page.

From:
https://www.nilab.at/dokuwiki/ - **NiLAB GmbH Knowledgebase**

Permanent link:
https://www.nilab.at/dokuwiki/doku.php?id=en:motolab_actuator:fixing

Last update: **2026/09/11 07:58**