

Wire connection

This page shows the **wire connection** of the NL-EB15 safety device. The device supports both PNP and NPN output types; the illustration below shows the wiring for each.

PNP type



NPN type



Wiring notes

- **PNP output**: the output switches the positive supply to the load (active high). - **NPN output**: the output switches the load to ground (active low). - Select the output type according to the PLC input and the wiring scheme. - Verify the supply voltage and the load current; refer to the technical parameters page.

From:
https://www.nilab.at/dokuwiki/ - **NiLAB GmbH Knowledgebase**

Permanent link:
https://www.nilab.at/dokuwiki/doku.php?id=en:nl_eb15_safety:connections

Last update: **2026/09/11 07:59**