Ordering code

This page explains how to build the **ordering code** of the NL-EB15 safety device. The code selects the model, the beam count, the beam space, the output type, and the sensing distance.

NL-EB15	-	**10**	**20**	**P**	**C**	**C**	-	**2**
Model		Beams	Beam space	Output signal	Output contact	Scanning method		Sensing distance
NL-EB15 series		04,06,08,10.12	10,20,40mm	P=PNP, N=NPN	C=normally close	C=cross scanning, P=parallel scanning		0,5⇒0.1 to 0,5m 2⇒0.1 to 2m 4⇒01, to 4m

Example: NL-EB15-10-20-P-C-C-2

How to build the code

- **Model**: NL-EB15 series. - **Beams**: number of beams (04, 06, 08, 10, 12). - **Beam space**: 10, 20, or 40 mm. - **Output signal**: P = PNP, N = NPN. - **Output contact**: C = normally close. - **Scanning method**: C = cross scanning, P = parallel scanning. - **Sensing distance**: 0.5, 2, or 4 m.

From:
https://www.nilab.at/dokuwiki/ - **NiLAB GmbH Knowledgebase**

Permanent link:
https://www.nilab.at/dokuwiki/doku.php?id=en:nl_eb15_safety:ordering

Last update: **2026/09/11 07:59**