

Messaggi di errore

Questa pagina elenca i **messaggi di errore** del servo azionamento Epulse50. Quando si verifica un errore, il drive segnala il messaggio e disabilita lo stadio di potenza — il motore non produce coppia.

Tutti i messaggi di errore disabilitano lo stadio finale del convertitore (il motore non ha coppia). Gli allarmi di tipo R possono essere azzerati dall'utente, gli allarmi di tipo B sono bloccanti. In quest'ultimo caso, per azzerare l'allarme, il convertitore deve essere spento e riacceso (C2-16, ALIMENTAZIONE DI CONTROLLO) per azzerare l'allarme.

CODICE	TIPO	DENOMINAZIONE	DESCRIZIONE
F00	B	Flash failure	Hw Fault FLASH memory parameters.
F01	R	Loaded default param.	User parameters reading fault.
F02	R	Loaded default protected	Factory parameters reading fault.
F03	-	riservato	riservato
F04	R	I ² t drive	Converter behavior when the maximum I ² t threshold is reached. P65 I2t settings: 0: Disable the converter once the threshold is reached 1: N.A. 2: When threshold is reached current is limited to In
F05	R	Overvoltage	DC-Link voltage has reached a dangerous limit.
F06	R	Undervoltage	DC-Link voltage goes under lower limit allowed.
F07	B	Power fail	Short circuit current on the output power stage.
F08	R	Heatsink temperature	Maximum allowed heatsink temperature is reached.
F09	R	Motor temperature	Maximum allowed motor windings temperature is reached.
F10	R	Regenerative resistance overload	Maximum load of regenerative resistance reached.
F11	R	Internal temperature	Maximum pcb temperature reached.
F12	R	Overcurrent regenerative circuit	N.A.
F13	R	Overvoltage 24V	N.A.
F14	R	-	N.A.
F15	-	-	N.A.
F16	R	Brake	Mechanical brake anomaly. Check break winding impedance and connection.
F17	R	-	N.A.
F18	R	-	N.A.
F19	R	Feedback	Feedback motor error.
F20	R	Feedback inizialization	Feedback initialization error.
F21	R	Curren over range	tCurrent exceeded the maximum allowed limit, decrease current Kp.
F22	-	reserved	N.A.
F23	-	reserved	N.A.
F24	-	reserved	N.A.
F25	-	reserved	N.A.
F26	R	Can Bus	Can communication interrupted.
F27	-	reserved	N.A.
F28	-	reserved	N.A.
F29	-	reserved	N.A.
F30	R	-	N.A.
F31	-	riservato	Non gestito

Leggere la tabella degli errori

- La tabella elenca i codici di errore, il tipo di allarme (R = azzerabile, B = bloccante) e la causa e la rimedio. - **Allarmi di tipo R** possono essere riconosciuti e azzerati dall'utente dopo che la causa è stata rimossa. - **Allarmi di tipo B** richiedono un ciclo di alimentazione (spegnimento e accensione dell'alimentazione di controllo) per l'azzeramento. - Rimuovi sempre la causa radice prima di azzerare l'allarme; un allarme ripetuto indica un guasto non risolto.

From:

<https://www.nilab.at/dokuwiki/> - **NiLAB GmbH**
Knowledgebase

Permanent link:

https://www.nilab.at/dokuwiki/doku.php?id=it:epulse50_dc_servodrive:error_messages

Last update: **2026/09/12 13:15**

