

Programming box DA012060 - cable connections

This page shows the **cable connections** of the programming box (DA012060) for the NLi integrated drive motors. The programming box is used to connect the PC to the motor during commissioning and firmware updates.


Programming box combined with NLi080Q or NLi080X motors

The illustration below shows the cable connection for the NLi080 motor series.



Programming box combined with NLi120Q or NLi120X motors

The illustration below shows the cable connection for the NLi120 motor series.



Connection notes

- Use the programming box to connect the PC to the motor for commissioning and firmware update. - Follow the cable connection shown for the respective motor series. - Verify the connector orientation and the pinout before connecting. - Refer to the connection system page for the full wiring of the motor.

From:

<https://www.nilab.at/dokuwiki/> - **NiLAB GmbH**
Knowledgebase

Permanent link:

https://www.nilab.at/dokuwiki/doku.php?id=en:integrated_drive_motors:prog_box

Last update: **2026/09/11 07:56**

