Tubular linear motor commisioning using TKSED Software

This page describes the **commissioning of a tubular linear motor** with the TKSED software. The software is used to parameterize the drive and the motor for the linear application.

Download the TKSED Software here: :mbd_servo_drive:nilab_byinterface-ver10.4.0_6_.zip

PDF Document: :mbd_servo_drive:tksed_linearmotor_parameterization_rev0.pdf

What TKSED is used for

- Parameterization of the drive for a tubular linear motor. - Setting the motor feedback, the pole pitch, and the commutation parameters. - Commissioning and testing of the linear motion. - The PDF document describes the parameterization procedure step by step.

How to proceed

- Download and install the TKSED software from the link above. - Connect the drive to the PC with the programming cable. - Follow the parameterization procedure described in the PDF document. - After commissioning, verify the motor operation and the position feedback.

From:
https://www.nilab.at/dokuwiki/ - **NiLAB GmbH Knowledgebase**

Permanent link:
https://www.nilab.at/dokuwiki/doku.php?id=en:mbd_servo_drive:linear_motor

Last update: **2026/09/11 07:57**