Rules for the use of the product

Transport

In order not to damage the product or avoid a product failure, it is required to follow the following rules:
• The transport must be made by qualified personnel and in original packaging.
• Avoid shocks or excessive pressure on the packaging
During transport the temperature must be between -20 °C and +75 °C
C, max. rate of change 20 °C/h
• Relative humidity max. 95%, noncondensing
• Avoid electrostatic discharge. Discharge its electrostatic charge before handling the servo amplifier; avoid contact with highly insulating materials as plastic materials or synthetic fabrics; place the servo amplifier on a conductive surface.
• In case of visible damage to the packaging, check the unit for visible damage and notify the shipper and the manufacturer.

Storage

• Only the original manufacturer's packaging
• Storage temperature -20 °C to +75 °C
• Storage relative humidity max. 95%, noncondensing

From:
https://www.nilab.at/dokuwiki/ - **NiLAB GmbH Knowledgebase**

Permanent link:
https://www.nilab.at/dokuwiki/doku.php?id=en:mbd_servo_drive:rules

Last update: **2026/09/11 07:57**