








MBM Connectors on motor side



M17 type connectors

			
Fixed side Feedback E - external view	Flying side Feedback P - external view	Fixed side Motor phases - external view	Flying side Motor phases - external view
	ASTA 876 - 09010002		BSTA 861 - 09020002

M23 type connectors

			
Fixed side Feedback E - external view	Flying side Feedback P - external view	Fixed side Motor phases - external view	Flying side Motor phases - external view
	ASTA 014 - 09010005		BSTA 085 - 09020004

M40 type connectors (Power only)

	
Fixed side Motor phases - external view	Flying side Motor phases - external view
	CSTA 263 FR5244 - 09020005

From:
<https://www.nilab.at/dokuwiki/> - **NiLAB GmbH**
Knowledgebase

Permanent link:
https://www.nilab.at/dokuwiki/doku.php?id=en:mbm_motors:motor_connectors

Last update: **2026/09/11 07:57**

