

CANopen over EtherCAT

This page describes the **CANopen over EtherCAT (CoE)** profile of the NLi-EtherCAT motor. The motor uses the DS402 profile over EtherCAT, which provides the standard modes of operation and the PDO/SDO communication.

Mode of operation:

https://www.nilab.at/dokuwiki/doku.php?id=integrated_drive_motors:canopen_modes

Standard PDOs: https://www.nilab.at/dokuwiki/doku.php?id=integrated_drive_motors:can_open_pdo

Standard SDOs: https://www.nilab.at/dokuwiki/doku.php?id=integrated_drive_motors:canopen_sdo

Error Codes: https://www.nilab.at/dokuwiki/doku.php?id=integrated_drive_motors:canopen_error

How to use the CoE profile

- The **mode of operation** defines the motion behaviour (profile position, velocity, torque, etc.). - The **PDOs** are used for cyclic data exchange (commands and status); the **SDOs** are used for parameter access. - The **error codes** are read from the drive and used for diagnostics. - Refer to the linked pages for the detailed object definitions and the mapping.

From:

<https://www.nilab.at/dokuwiki/> - **NiLAB GmbH**
Knowledgebase

Permanent link:

https://www.nilab.at/dokuwiki/doku.php?id=en:nli_eth:coe_profile

Last update: **2026/09/11 07:59**

