



# How to mount the stator



## GDI250..




SECTION A-A

GDI250	L (mm)
TS	183
QS	204
XS	333

## GDI350..



SECTION A-A



GDI350	L (mm)
TS	188
QS	217
XS	342
ES	468

From:  
<https://www.nilab.at/dokuwiki/> - NiLAB GmbH  
Knowledgebase

Permanent link:  
[https://www.nilab.at/dokuwiki/doku.php?id=green\\_drive\\_iso:fixing\\_point](https://www.nilab.at/dokuwiki/doku.php?id=green_drive_iso:fixing_point)

Last update: 2026/02/17 08:05

