


# Connectors



Rotoliner motor has 3 x M12 connectors (standard version) and 4 x M12 connectors (CanOPEN version).

L1 and L2 are the status led for linear and rotary motor.

Connector	Function	Type
C1	Power connector	M12, 5 poles male
C2	Signal connector for linear side	M12, 8 poles female
C3	Signal connector for rotary side	M12, 8 poles female
C4	CanOPEN connector	M12, 5 poles female

For pinout of the connectors on the relative cable, please see:  
[https://www.nilab.at/dokuwiki/doku.php?id=integrated\\_drive\\_motors:connection\\_system](https://www.nilab.at/dokuwiki/doku.php?id=integrated_drive_motors:connection_system)

From:

<https://www.nilab.at/dokuwiki/> - **NiLAB GmbH**

**Knowledgebase**

Permanent link:

[https://www.nilab.at/dokuwiki/doku.php?id=integrated\\_rotoliner:connections](https://www.nilab.at/dokuwiki/doku.php?id=integrated_rotoliner:connections)

Last update:

**2024/09/23 07:54**

