Motion controller

Position table

The motion controller window is used to specify the motion sequences. It is based on 10 row tables. Every row configures the motion task with these parameters:

1. Motion type: trapezoidal, triangular, polinomial, sinusoidal or force
2. Target position
3. Acceleration, deceleration and constant speed time depending on the motion profile used
4. Waiting time
5. Trigger mode: automatic, rising edge, falling edge, high and low level of trigger input (Digital input 1)







PLEASE IN ORDER TO STORE PERMANENTLY THE CONFIGURATION - PRESS THE WRITE CONFIGURATION TO FLASH



From:
https://www.nilab.at/dokuwiki/ - **NiLAB GmbH Knowledgebase**

Permanent link:
https://www.nilab.at/dokuwiki/doku.php?id=nilab_starter:motion_controller

Last update: **2025/11/19 13:31**