

Safety

Introduction

The MBD digital amplifier brushless synchronous servomotors and can be supplied from 3-phase at 230/400 VAC, 50/60 Hz. In its standard version it is equipped with CANopen field bus, incremental encoder, digital inputs and outputs, two slots for optional expansion cards are available.

1.1 Manual

The digital amplifiers are devices powered by dangerous high voltages designed to control electric motors installed in equipment with axes in motion. This manual contains instructions for installing and handling them safely. Read this manual carefully before taking any action concerning the device.

	<p>RISK OF ELECTRICAL TYPE INJURY. Indicates a hazardous situation that, if not avoided, can result in death or in serious and permanent injuries. Do not work on the device if the voltage is connected. Wait at least 5 minutes, after disconnecting the servo amplifier from the mains power supply, before touching the device.</p>
	<p>GENERAL HAZARD. Indicates a hazardous situation that, if not avoided, can result in death or serious and permanent injuries</p>
	<p>RISK OF BURNS. Due to the hot surfaces of the metal case.</p>

1.2 Warnings

	<p>Do not open or touch the equipment while it is running or if the power supply is connected. On the equipment may be present:</p>
	<p>voltage even though the motor is not rotating temperature above 75°C</p>
	<p>Warning: Read this documentation before installing and commissioning the MBD digital amplifiers. An incorrect use or handling of the digital amplifier may cause damage or injury. Follow the instructions of connection, commissioning and maintenance. Permit to carry out these activities only qualified technicians who have the appropriate qualifications for conducting such activities</p>
	<p>The company uses the product must produce a risk assessment and takes appropriate measures to ensure that unforeseen movements do not result in material damage or personal injury.</p>



The servo amplifiers contain electrostatically sensitive components which may be damaged by these phenomena. It's important to follow all the precautions in order to not produce discharge when handling the product. Observe the following guidelines:

discharge its electrostatic charge before handling the servo amplifier;

- avoid contact with highly insulating materials as plastic materials or synthetic fabrics;
- place the servo amplifier on a conductive surface

From:

<https://www.nilab.at/dokuwiki/> - **NiLAB GmbH**
Knowledgebase

Permanent link:

https://www.nilab.at/dokuwiki/doku.php?id=mbd_servo_drive:safety

Last update: **2023/09/21 07:16**

